

Troubleshooting Continued:

- Read the "One For All's" troubleshooting section of the guide for any additional troubleshooting tips.
- Try ALL of the codes listed for your device. Many set-up codes may allow partial functionality; however, only one code will operate your device correctly.
- Make sure that you are within 6-10 feet of your device, with the remote facing the device, while programming. Make sure that you are within 15 feet of your device when using your remote.
- If the red light on the remote control does not blink when you press a key, replace the batteries with two (2) new AA alkaline batteries. Be sure to install paying close attention to proper battery polarity. *.
- * NOTE: When you replace your batteries, or remove them for any reason, you must re-install batteries within 10 minutes, or re-programming your remote will be required. This is why it is important to write down the codes that work for your devices and keep both these manuals in a safe place.

Care of Unit:

The Universal Remote can be wiped clean with any household multi-purpose cleaner and disinfectant.

Do not submerge the unit, as it will damage the contents and the electrical components.

Do not use abrasive cleaners, as they will scratch the surface of the unit.

For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-TEC-TOYS or 1-800-832-8697
customer_support@enablingdevices.com

Jumbo Universal Remote Control #1526

USER'S GUIDE

The logo for Enabling Devices features the company name in a serif font. Above the word "Enabling" is a stylized graphic of a curved line with an arrow pointing upwards and to the right, ending in a small star.

50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

An all-in-one remote control!

Allows the user to easily see and push buttons to control TV, VCR, DVD, Cable, PVR, DTC Boxes and Satellite receivers. It also will control the latest Flat Screen TV's. The large buttons are very sensitive to touch and have different colors for different group functions.

Size: 18"L x 10"W x 2½"H. Requires 2 AA Batteries. Weight: 2 lbs.

Operation:

1. The Universal Remote requires 2 AA batteries (Not included). Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
3. You will not be placing any batteries directly into the "One For All" remote as this is permanently affixed to the Universal Remote. Instead, please locate the battery compartment recessed in the back of the Universal Remote. The battery compartment cover is secured with a small screw. Use a Phillips head screwdriver to remove this screw and remove the cover. Insert the 2 AA batteries into the compartment paying careful attention to proper battery polarity.
4. Replace the compartment cover and re-secure it with the screw. Test the unit by pressing the ON/OFF button. The red indicator light should blink. If not, change your batteries.
 - All programming will be done through the remote's keypad on the back of this unit. When programming make sure none of the large buttons on the front become activated or depressed, doing so will prevent programming of your device.
5. Turn on a desired device (e.g. VCR or DVD player) and, if applicable, insert media (e.g., cassette or disc). On the remote control, press a device key once (i.e., **DVD/VCR**, **CBL/SAT**, or **TV**).

NOTE: To program control of a VCR, PVR (or DVR), TV/VCR Combo, or TV/VCR/DVD Player Combo press **DVD/VCR** once. After programming a VCR Combo device, you will be able to control channel selection, volume, and VCR functions.

NOTE: To program control of a DVD Player, DVD Player/VCR Combo, or TV/DVD Player Combo, press **DVD/VCR** once. After programming a DVD Combo device, you will be able to control channel selection, volume, and DVD functions.

NOTE: To program control of a Cable Box, Cable Box/PVR (or DVR) Combo, Satellite Receiver, or a Satellite Receiver/PVR (or DVR) Combo, press **CBL/SAT** once.

6. Press and hold **SET** until the **LED** (red light) blinks twice, then release **SET**. Use the *Manufacturer's Codes* to locate the type of device and brand name and then enter the first four-digit code for your device. If performed correctly, the **LED** will blink twice.
7. **NOTE: If the LED did not blink twice, repeat steps 6 through 7 and enter the same code again.** Aim the remote control at the device and press **POWER** once. The device should turn off. If it does not, repeat steps 6 through 7, trying each code for your brand until you find one that works.

Volume Setting:

8. To have control of your T.V. volume while running a DVD, VCR, PVR or CBL/SAT, you will need to lock the Volume as described on page 8 in the "One For All" instructions. Press and hold SET button until the red light on the remote blinks twice, then release. Enter 9-9-3 and then press T.V. key once the Red light will blink twice. Now when you press Vol up, Vol down or Mute it will be controlled regardless of the device you are controlling.

Troubleshooting:

If you cannot get your Universal Remote to operate any of your devices, or it will not perform commands properly:

- Make sure that your batteries are fresh and installed correctly (according to proper polarity). *